



1. Open the carton and remove the packing material. If you ordered Dividers remove the small box containing them.



2. Fold the short carton flaps in and flip the cabinet box on it's end. Use the hand holes on the carton to avoid bending.



3. Slide the cabinet out of the box onto the flap. Tear the top of the bag open and slide it down the cabinet.



4. Plastic bags can be dangerous. As soon as you have set the cabinet down, gather up the bag and all the packing material.



5. Check the levelers. If you are stacking this cabinet, or using a caddy, the levelers should be all the way in. If this is the base cabinet, the levelers will be used to level the cabinet. The levelers will also serve to lift the cabinet off the floor slightly. This is especially important on carpeting. You want the levelers carrying the weight - not the bottom of the cabinet. Tilt the cabinet forward and backward to access the levelers when it is in position and ready to be leveled.



6. Set the cabinet down gently. The cabinet should be leveled precisely where it will be used. Use a level and be sure the cabinet does not wobble. If you are stacking the cabinet you **must** use the safety C-Clamps provided to join the cabinets. Slide the C-Clamp Tabs into the holes at the rear of the cabinets ensuring the tiny slats in the tabs are pointing down and forms the letter "C" from the rear when installed. Any questions? Feel free to call us during office hours EST.